

1- the kitchen tap does not activate the water pump. The technician has replaced it.

2-The upper hinge of the cupboard door under the kitchen is loose. the technician has repaired the area where the screws are fixed and has mounted it with new screws.

3- the profile of the dining room floor sinks when the customer steps on it. the technician has reinforced the profile with supports.





