

water always comes out from under the fridge.

The drain pipe is incorrectly assembled. The technician has had to remove the refrigerator completely, for this he has had to remove the wood from the side. then he has put the tube correctly and has fixed it so that it does not move. has assembled the refrigerator and has tested the correct operation.





